

# INSTALLATION INSTRUCTIONS

## 玻璃掛勾安裝說明

1. Available thickness of glass is 6~12mm; requested dimension of hole on glass is 14mm.  
使用玻璃厚度6~12mm，鑽孔尺寸 $\phi$ 14mm.
2. Double Robe Hook: Insert **Hook Body** with **Screw Bolt** through glass with **Rubber**, screw and tighten **Locking Base** with **Rubber** on **Screw Bolt** (please make sure glass is between two **Rubbers**.), and then fix the other **Hook Body** with **Set Screw** by **2MM Hex Key** wrench.  
雙邊:掛勾本體底座套入橡皮墊支撐在玻璃一邊,將另一邊橡皮墊套入鎖定底座鎖入螺桿,掛勾本體套入用六角扳手2MM將埋頭螺絲固定。
3. Single Robe Hook: Fix single **Hook Body** on glass with **Rubbers** and **Locking Base** securely, and please make sure glass is between two **Rubbers**.  
單邊:掛勾本體底座套入橡皮墊支撐在玻璃一邊,將另一邊橡皮墊套入鎖定底座鎖入掛勾本體。

